



# MW-NON-PEN ROOF MOUNT ASSEMBLY INSTRUCTIONS

## CONTENTS OF KIT:

- 1 ea. 57.5" galvanized steel pole
- 2 pcs 35" angle base
- 4 pcs 29" angle base
- 2 pcs 24" angle support
- 2 pcs 17" adjustment strut, Parts 1 & 2
- 1 package of nuts/bolts

1. Build base frame with small bolts.
2. Insert bolts so bolts are on the bottom of the unit and nuts are on top.
3. Assemble strut slider with two small bolts/nuts
4. Insert pipe into base frame with 3" bolt and connect with two outside angle supports
5. Attach angle supports to base frame
6. Position pipe angle as needed and tighten all nuts

